

Guide Navigation

1. Supported Features for the Schlage.
2. How to link Linxura with Schlage.
3. How to use Linxura to control Schlage device.

Schlage Setup Guide Video Link:

1. Supported Features for the Schlage

Schlage Supported Actions

Actions	Supported Mode	Descriptions
Click/Double Click	Mode: Lock, Unlock, Toggle lock/unlock	Lock: Lock the Schlage lock. Unlock: Unlock the Schlage lock. Toggle lock/unlock: Toggle lock/unlock the Schlage lock.


2. How to link Linxura with Schlage.

Step 1:

Make sure your Schlage device is set up in the Schlage app and functioning properly.


Step 2:

Open your Linxura app and then select the Linxura you want to bind with Schlage.




Step 3:


Choose a button.




Step 4:
Click 'Select platform'.




Step 5:
Select the 'Schlage Locks' option.




Step 6:
Click 'Confirm' to complete the authorization.



Step 7:
Log in to your Schlage account.




Step 8:
Select the Schlage device and click 'Save'.




3. How to use Linxura to control the Schlage device.


Step 1:
Click the '+' icon to add a Click Action.




Step 2:
Click 'Mode'.



Step 3:
Select one of the 'Mode' options.



Step 4:
Click the 'Save' to save the configuration.



Step 5:
You can follow the same steps to configure Double Click.

You can now use Linxura to control your Schlage device!

