

Guide Navigation

1. Supported Features for the Ultraloq.
2. How to link Linxura with Ultraloq.
3. How to use Linxura to control Ultraloq device.

Ultraloq Setup Guide Video Link: <https://youtu.be/5F6yOG0l5Dg>

<https://www.linxura.com/pages/ultraloq>

1. Supported Features for the Ultraloq

Ultraloq Supported Actions

Actions	Supported Mode	Descriptions
Click/Double Click	Mode: Lock, Unlock, Toggle Lock/Unlock	Lock: Lock the Ultraloq lock. Unlock: Unlock the Ultraloq lock. Toggle Lock/Unlock: Toggle the door lock or unlock.


2. How to link Linxura with UltraIQ.

Step 1:

Make sure your UltraIQ device is set up in the UltraIQ app and functioning properly.


Step 2:

Open your Linxura app and then select the Linxura you want to bind with UltraIQ.




Step 3:


Choose a button.




Step 4:
Click 'Select platform'.



Step 5:
Select 'Ultralog' option.



Step 6:
Click 'Confirm' to complete the authorization.




Attention

Authorization required.




Step 7:
Log in to your Ultraloq account.




Step8:

Enter verification code, click 'AUTHORIZE' and follow the instruction in the web page.




Step 9:

Select the UltraIQ device and click 'Save'.



Step 8:


The default configuration for **Click, Double click** will be created automatically.




3. How to use Linxura to control the UltraIQ device.

Step 1:


Click the '+' icon to add a Click Action.




Step 2:
Click 'Mode'.



Step 3:
Select one of the 'Mode' options.



Step 4:
Click the 'Save' to save the configuration.



Step 5:
You can follow the same steps to configure Double Click.

You can now use Linxura to control your UltraLoq device!

